

PLEASE READ THE ENTIRE INSTRUCTIONS CAREFULLY BEFORE USING THIS PRODUCT

**STEP 1: PREPARATION: ITEMS AND TOOLS NEEDED**

UTILITY KNIFE	CONTACT CEMENT
LEVEL	HELPFUL ACCESSORIES
METAL RULER	WALLPAPER SEAM ROLLER
ADHESIVE OPTIONS FOR INSTALLATION	PAINTING SUPPLIES
POLYMER ADHESIVE	JOINT COMPOUND
TYPE 1 TILES ADHESIVE	DRYWALL
TILE SPACERS (optional)	PRIMER / SEALER
	<u>"Dulux" Emulsion Paint</u>

**STEP 2: INITIAL SURFACE PREPARATION**

The product is made to install over relatively smooth flat surfaces. The surface must be clean, dry and free of loose debris. All the central holes or significant damage that could interfere with installation must repair before installation. When installing over glossy plaster or paint rough up the surface with sandpaper to dull the surface and create a tooth for bonding.

**STEP 3: TILE PREPARATION**

Tiles should acclimate for 48 hours in the environment and temperature they will be installed.

**STEP 4: INSTALLING WALL PANELS**

You must determine if the installation will be wall-to-wall, a free design (leave an even border all around to avoid cutting), a strip of tiles, etc. It is important to have this well-thought-out before beginning. If you are unsure, lay the tiles out on the floor or draw a grid on the wall to help you decide.

**USING A PERMANENT ADHESIVE**

For permanent installations, all commercial applications and tricky climatic conditions, we recommend the use of one of the resins mentioned above. Follow the manufacturer's instructions for adhesive use. If you notice a tile with a slight bow, it can gently be flexed to help it lay as flat as possible before adhering to the wall. Pay close attention to the edges and ensure they are as close to 100% flat as possible. Use a wallpaper seam roller for this will be very helpful. Take care in making sure the tiles are butted as tightly as possible to one another; this will help minimise seams. Mastic will likely get on the roller and the tiles during installation, keep a damp rag handy to wipe off. It does not hurt the tiles, or the roller cleaned while wet. Minimise cleaning as much as possible on tiles that have not primed before going on the wall. Blot as much as possible and wipe excess when needed. Excessive wiping with a damp rag on unprimed tiles can cause the tiles to ball up small amounts of pulp.

**PLACING THE TILES ON THE WALL**

Regardless of the adhesion method, the tiles go on the wall the same way. The first panels that are positioned to be as straight as possible. Take extra care when placing these tiles. Use a level to ensure proper alignment and take wall irregularities and other obstacles into account early on. The tiles should be put next to each other if desired, paying particular attention to fitting them as close as possible to minimise the seams. On a wall-to-wall install, when at all possible, work across the wall, moving toward the corner from the top, to reduce cutting, and the cut tiles will fall in more hidden areas. If you work from the centre out, keep in mind the tiles that fall at the top, bottom and both edges will need to cut. Plan your design well to ensure desired results are what you expect. Remember, measure twice and cut once.

#### **CUTTING THE TILES**

In most installations, you will probably need to cut some tiles. The tiles will cut with a standard utility knife. Make multiple passes on the tiles, cutting deeper each time, as this will help to ensure a straight cut. After cutting, use 350 grit sandpaper for sanding the cut edge lightly

#### **FILLING GAPS**

With a modular product, it is inevitable that you will have seams. If your wall is not completely straight, a tile is slightly out of position, or you come to a corner where you have to cut a tile this situation may exaggerate. These quickly addressed with paintable caulk or joint compound. Address seam issues before finish painting and after priming. Make sure you are happy with the tile adhesion before applying because it will crack or pull out of the joints if the panel pulled away from its position. Allow proper dry time, and reapply if needed. Sand the seams lightly with a 350 grit sandpaper if needed, and brush away debris with a slightly damp rag. Pay attention when using joint compound to manufacturers, recommended temperature usage while wet. Minimise wiping as much as possible on tiles that have not primed before going on the wall. Blot as much as possible and wipe excess when needed. Excessive wiping with a damp rag on unprimed tiles can cause the tiles to ball up small amounts of pulp.

#### **PRIMER AND FINAL SANDING**

After all, tiles are up, and the seams have filled, apply a light coat of sandable drywall primer/sealer. After the primer dries, we recommend a quick, light and gentle sanding over by removing any foreign debris accrued on the panel during the installation process; this will help ensure a smooth surface for the painting process. Use a 350 grit or higher sandpaper.

#### **STEP 5: PAINTING ( We recommend to use – “Dulux” Emulsion Paint)**

The wall panels are now ready to be painted. If you followed the preparation and installation instructions carefully, you should now have a tile wall willing to accept latex paint. The tiles can be brushed, rolled, or sprayed. When using a permanent adhesive method, spraying the tiles is fine. In this instance, multiple light misting coats are preferred to one thick coat, to avoid oversaturation of tiles. Follow the paint manufacturer’s instructions on the paint chosen for some layers, climatic and environmental conditions, dry times, etc. If you are using professional painters or wallcovering installers, work with them to achieve the desired effect!

#### **All kind of Joint Compound used:**

- Paintable Caulk
- Hydrated lime
- Slaked lime
- Painters Putty
- Paintable Acrylic Caulk